

Displays, Software, Technical Manuals

DISPLAYS

	Ordering code
"Tico" display for connection T, AC58 Profibus, AC58 DeviceNet	0 731 205
"Tico" display for connection T (Caution: Neutralizes ohmic isolation) AC58 CANopen, AC58 CANLayer2	0 731 205
Connection cable bus cover (connection T) to "tico", 1.5 m, AC58 Profibus, AC58 CANopen, AC58 CANLayer2, AC58 DeviceNet	3 539 516
Position indicator Signo-SS, AC58 BiSS/SSI, AC58 SSI-P	0 727 111

SOFTWARE

	Ordering code
EDS-file, as download from our homepage, AC58 CANopen, AC58 DeviceNet, AC61 CANopen, AC61 DeviceNet, AX70/71 CANopen	www.hengstler.com
EDS-file, as download from our homepage, AC58 Profibus, AC61 Profibus, AX70/71 Profibus	www.hengstler.com
Software Win SSI, as download from our homepage, AC 58 SSI-P, AC 61 SSI-P	www.hengstler.com
Software Win SSI, AX70/71 SSI-P	on request
Win SSI PC connecting cable, for M23 (Conin), 12 pole, ccw (suited for supply voltage E and connection G or H), AC58 SSI-P	1 543 010

TECHNICAL MANUALS

	Ordering code
Technical manual, German, AC58 Profibus, AC61 Profibus, AX70/71 Profibus	2 565 090 (or homepage)
Technical manual, English, AC58 Profibus, AC61 Profibus, AX70/71 Profibus	2 565 255 (or homepage)
Technical manual, German, AC58 CANopen, AC61 CANopen, AX70/71 CANopen	2 565 250 (or homepage)
Technical manual, English, AC58 CANopen, AC61 CANopen, AX70/71 CANopen	2 565 329 (or homepage)
Technical manual, German, AC59/61 DeviceNet	2 565 094 (or homepage)
Technical manual, English, AC59/61 DeviceNet	2 565 256 (or homepage)
Technical manual, German, AC58 Interbus, AC59/61 Interbus	2 565 217 (or homepage)
Technical manual, German, AC58 SUCOnet	2 547 080 (or homepage)
Technical manual, English, AC58 SUCOnet	2 547 081 (or homepage)
Technical manual, German, AC58 SSI-P, AC61 SSI-P, AX70/71 SSI-P	2 565 287 (or homepage)
Technical manual, English, AC58 SSI-P, AC61 SSI-P, AX70/71 SSI-P	2 565 289 (or homepage)